

. BOARD

N F. MARK

1. BIKALES Foundati n

ERBERGER of Michigan

G MENGES /TH Aachen

it r-in-Chief LOSCHWITZ

ENCYCLOPEDIA OF POLYMER SCIENCE AND ENGINEERING

VOLUME 4

Composites, Fabrication to Die Design

A WILEY-INTERSCIENCE PUBLICATION

John Wiley & Sons

NEW YORK • CHICHESTER • BRISBANE • TORONTO • SINGAPORE

360 CROSS-LINKING

V 1. 4

are generally improved on cross-linking. Among other properties, thermal expansion and heat capacity are lowered, and heat distortion temperature, tensile strength, and refractive index are raised. Glass-transition temperature increases with increasing cross-link density (26). The increase ΔT_g in glass-transition temperature can be approximated by the following relationship:

$$\Delta T_g = A \nu \tag{23}$$

where $\nu=$ moles of cross-links per gram of polymer and the constant A is of the order 10^4-10^5 . For styrene-divinylbenzene polymerization ($A=7\times10^4$), the elevation in T_g is 12°C for a cross-link density change of 10^{20} cross-links per gram of polymer. For natural rubber cross-linked with dicumyl peroxide, ΔT_g is 6°C for the same change in cross-link density (27).

If a material is cured (cross-linked) isothermally at cure temperature $T_{\rm cure}$, the rise in T_g reduces the chain mobility, and as T_g approaches $T_{\rm cure}$ the reaction may become diffusion controlled and eventually stop as the system undergoes vitrification (28). Complete cure is therefore obtained by curing at a temperature that is above the ultimate glass-transition temperature $T_{g\infty}$ of the system (29). Isothermal time-temperature-transformation (TTT) diagrams may be used to describe the various stages of cure in a thermosetting polymer (see Curing). Figure 5 shows a TTT diagram indicating regions of ungelled glass, liquid, gelled glass, gelled rubber, and char (30). At a very high temperature, the material decomposes to form char. Although the chemical reaction is extremely slow below T_g , sufficient reaction can take place over longer periods of time so that upon aging (qv) T_g may rise to 40°C above $T_{\rm cure}$.




Fig. 5. Time-temperature-transformation (TTT) diagram.

· ··

-

used f tional rying with c Techn

I

I

, , ,

£

I

•